



DIMMER NO.	SOCKET BOX NO.	PLUG NO.	DIMMER NO.	SOCKET BOX NO.	PLUG NO.
1	FOH 1, FOH 2	47, 48	13	G6, G7	35, 36
2	FOH 3, FOH 5	49, 51	14	F4, F10	21, 27
3	FOH 7, FOH 8	53, 54	15	F5	22
4	F3, G4	20, 31	16	B2, B5	5, 8
5	D3, J1	14, 45	17	B4	7
6	F2, G2	19, 31	18	B3	6
7	B1, B6	4, 9	19	F6, F9	23, 26
8	D1	12	20	F1	15
9	D2	13	21	F2	16
10	G3, G10	32, 39	22	F3	17
11	F1, F12	18, 29	23	C1	10
12	G8, G12	37, 41	24	FOH 4	50
UV	A1, G13, G14	42, 43			