

Lantern #	Lantern	Wattage	Plugging	Pairing	Chan/Dim #	Position	Focus	Purpose	Colour	Gobo
1	Cantata 18/32	1000	A1	-	1	LX 1	DSR	General DSR Cool Cover	202	-
2	Cantata 18/32	1000	A2	-	7	LX 1	DSR	General DSR Warm Cover	205	-
3	Cantata 18/32	1000	A3	-	2	LX 1	DSC	General DSC Cool Cover	202	-
4	Cantata 18/32	1000	A4	-	8	LX 1	DSC	General DSC Warm Cover	205	-
5	Cantata 18/32	1000	A5	-	3	LX 1	DSL	General DSL Cool Cover	202	-
6	Cantata 18/32	1000	A6	-	9	LX 1	DSL	General DSL Warm Cover	205	-
7	Cantata 18/32	1000	B1	-	4	LX 3	CSR	General CSR Cool Cover	202	-
8	Cantata 18/32	1000	B2	-	10	LX 3	CSR	General CSR Warm Cover	205	-
9	Cantata 18/32	1000	B3	-	5	LX 3	CS	General CS Cool Cover	202	-
10	Cantata 18/32	1000	B4	-	11	LX 3	CS	General CS Warm Cover	205	-
11	Cantata 18/32	1000	B5	-	6	LX 3	CSL	General CSL Cool Cover	202	-
12	Cantata 18/32	1000	B6	-	12	LX 3	CSL	General CSL Warm Cover	205	-
13	Cantata F	1000	G1	16	13	LX 2	DSR	General Blue DSR Wash	141	-
14	Cantata F	1000	G2	17	14	LX 2	DSR	General Gold DSR Wash	15	-
15	Cantata F	1000	G3	18	15	LX 2	DSR	General Pink DSR Wash	328	-
16	Cantata F	1000	G1 (G+5)	13	13	LX 2	DSL	General Blue DSL Wash	141	-
17	Cantata F	1000	G2 (G+5)	14	14	LX 2	DSL	General Gold DSL Wash	15	-
18	Cantata F	1000	G3 (G+5)	15	15	LX 2	DSL	General Pink DSL Wash	328	-
19	Cantata F	1000	G4	20	INDEP	LX 2	SR	Red Wash over Stage (SR)	106	-
20	Cantata F	1000	G4 (G+5)	19	INDEP	LX 2	SL	Red Wash over Stage (SL)	106	-
21	Cantata F	1000	C1	24	16	LX 4	USR	General Blue USR Wash	141	-
22	Cantata F	1000	C2	25	17	LX 4	USR	General Gold USR Wash	15	-
23	Cantata F	1000	C3	26	18	LX 4	USR	General Pink USR Wash	328	-
24	Cantata F	1000	C1 (G+5)	21	16	LX 4	USL	General Blue USL Wash	141	-
25	Cantata F	1000	C2 (G+5)	22	17	LX 4	USL	General Gold USL Wash	15	-
26	Cantata F	1000	C3 (G+5)	23	18	LX 4	USL	General Pink USL Wash	328	-
27	Cantata F	1000	C5	-	19	LX 3A	CSL	Cool sidelight to L	165	-
28	Cantata F	1000	C4	-	21	LX 3A	CSL	Warm sidelight to R	111	-
29	Cantata F	1000	F1	-	20	LX 3A	CSR	Cool sidelight to L	165	-
30	Cantata F	1000	F2	-	22	LX 3A	CSR	Warm sidelight to R	111	-

Lantern #	Lantern	Wattage	Plugging	Pairing	Chan/Dim #	Position	Focus	Purpose	Colour	Gobo
31	Cantata F	1200	D1	36	23	LX 6	SR	Cool Backlight	200/228	-
32	Cantata F	1200	D2	35	24	LX 6	SR	Warm BackLight	147/228	-
33	Cantata F	1200	D3	34	INDEP	LX 6	SR	Red Backlight	106	-
34	Cantata F	1200	D3 (G+5)	33	INDEP	LX 6	SL	Red Backlight	106	-
35	Cantata F	1200	D2 (G+5)	32	24	LX 6	SL	Warm BackLight	147/228	-
36	Cantata F	1200	D1 (G+5)	31	23	LX 6	SL	Cool Backlight	200/228	-
37	Coda 500/3	500	D4	40, 43	37	LX 6A	Cyclorama	Red Cyclorama	106	-
38	Coda 500/3	500	D5	41, 44	38	LX 6A	Cyclorama	Green Cyclorama	139	-
39	Coda 500/3	500	D6	42, 45	39	LX 6A	Cyclorama	Blue Cyclorama	132	-
40	Coda 500/3	500	D4	37, 43	37	LX 6A	Cyclorama	Red Cyclorama	106	-
41	Coda 500/3	500	D5	38, 44	38	LX 6A	Cyclorama	Green Cyclorama	139	-
42	Coda 500/3	500	D6	39, 45	39	LX 6A	Cyclorama	Blue Cyclorama	132	-
43	Coda 500/3	500	D4	37, 40	37	LX 6A	Cyclorama	Red Cyclorama	106	-
44	Coda 500/3	500	D5	38, 41	38	LX 6A	Cyclorama	Green Cyclorama	139	-
45	Coda 500/3	500	D6	39, 42	39	LX 6A	Cyclorama	Blue Cyclorama	132	-
46	Minuette Profile	500	E5 (G+10)	59	27	LX 1	DSR	DSR Area Front Light	206	-
47	Minuette Profile	500	F6 (G+10)	66	28	LX 1	DSL	DSL Area Front Light	206	-
48	Quartet 22/40	500	G5	49, 50, 67, 68	41	LX 3	Hardish - DS	Soft Warm Break-up	176	M811
49	Quartet 22/40	500	G5 (G+5)	48, 50, 67, 68	41	LX 3	Hardish - DS	Soft Warm Break-up	176	M811
50	Quartet 22/40	500	G5 (G+5)	48, 49, 67, 68	41	LX 3	Hardish - DS	Soft Warm Break-up	176	M811
51	Minuette F	500	F5 (5)	-	29	LX 7	DSR	DSR Top Light	205	-
52	Minuette F	500	F4	-	30	LX 8	DSL	DSL Top Light	205	-
53	Quartet 22/40	500	C6	54, 55, 56	42	LX 4	SL	Soft Cool Break-up	117	M238-232
54	Quartet 22/40	500	C6 (G)	53, 55, 56	42	LX 4	SL	Soft Cool Break-up	117	M238-232
55	Quartet 22/40	500	C6 (G+5)	53, 54, 56	42	LX 4	SR	Soft Cool Break-up	117	M238-232
56	Quartet 22/40	500	C6 (G)	53, 54, 55	42	LX 4	SR	Soft Cool Break-up	117	M238-232
57	Pattern 252	2000	F3 (5)	-	40	LX 3A	Cyclorama	Moving Clouds F/X on Cyclorama	-	-

Lantern #	Lantern	Wattage	Plugging	Pairing	Chan/Dim #	Position	Focus	Purpose	Colour	Gobo
58	Colour Scroller	N/A	INDEP	N/A	43	LX4	N/A	Colour Change for Pattern 252	Scroll	N/A
59	Minuette F	500	E5 (5)	46	27	LX 5	DSR	DSR Area Backlight	204	-
60	Minuette F	500	E6 (5)	-	26	LX 5	USR	Special for Jud (Ballet)	201	-
61	Prelude 28/40	500	E2	63	32	LX 5	Cyclorama	Gobo on Cyclorama	174	B441
62	Cantata 18/32	1000	E1	-	33	LX 5	CS	CS Toplight	202	-
63	Prelude 28/40	500	E2 (G)	61	32	LX 5	Cyclorama	Gobo on Cyclorama	174	B441
64	Silhouette 15	1000	E3	-	35	LX 5	Cyclorama	Moon Gobo Special	202	Moon (GL)
65	Cantata 18/32	1000	E4 (5)	-	34	LX 5	CSL	'Preacher Light' Special	202	-
66	Minuette F	500	F6 (5)	47	28	LX 5	DSL	DSL Area Backlight	204	-
67	Quartet 22/40	500	G5 (G+5)	48, 49, 50, 68	41	LX 6	USR	Soft Warm Break-up	176	M811
68	Quartet 22/40	500	G5 (G+10)	48, 49, 50, 67	41	LX 6	USL	Soft Warm Break-up	176	M811
69	M16 Birdie	50	H1	-	25	LX 6	USC	'Gun Shot' Special	O/W	-
70	Quartet 22/40	500	H3	71	36	LX 6	USC	Window Gobo Special	201	M136
71	Minuette F	500	H2	70	36	LX 8	USC	Smokehouse Door Light Special	201	-
72	M16 Birdie	50	H4	73, 74, 75, 76, 77	31	Forestage	US	Cool Up-light	204	-
73	M16 Birdie	50	H4	72, 74, 75, 76, 77	31	Forestage	US	Cool Up-light	204	-
74	M16 Birdie	50	H4 (G+5)	72, 73, 75, 76, 77	31	Forestage	US	Cool Up-light	204	-
75	M16 Birdie	50	H4	72, 73, 74, 76, 77	31	Forestage	US	Cool Up-light	204	-
76	M16 Birdie	50	H4 (G+5)	72, 73, 74, 75, 77	31	Forestage	US	Cool Up-light	204	-
77	M16 Birdie	50	H4	72, 73, 74, 75, 76	31	Forestage	US	Cool Up-light	204	-
78	Nocturne Flood	1000	J1	79	INDEP	LX 7	Auditorium	House Lights	O/W	-
79	Nocturne Flood	1000	J1 (G+5)	78	INDEP	LX 8	Auditorium	House Lights	O/W	-